

## Rodman

This thermostat controls the temperature of the air entering the room through the ceiling vents above.

To adjust the thermostat you would move the slider located below to the right to raise the temperature and move it to the left to decrease the temperature.

If you have any concerns about the heat in your building, please contact the Facilities Department at 216.397.4314 or submit a work order online during normal business hours.



## Winter Break Settings

Close and lock all windows.

Set Danfoss valves to 2 or above.

Set the slider to the medium warm setting.

Remove books, papers and personal items from perimeter heating covers so warm air can circulate.

Remove all food from offices and kitchens

Please note that during the Winter Break the Facilities Department will never turn off the heat to the campus buildings nor reduce the temperature setting below 60 degrees.

Please report any low temperature conditions over the Winter Break to the JCU PD at 397-1234.

Revised 12/2018